
Instruction to update the system software for the following Contex Scanner models:

- SD One MF
- IQ FLEX

NOTE: This guide will use images, screenshots and references to the SD One MF scanner model, however the same process is equivalent when applied to any other above mentioned model


Browse the Contex support site (http://support.contex.com) and find the latest relevant Contex Scanner model software

Click the link to download the file.



The downloaded file should be unzipped and saved to the root of a USB memory stick

NB: The USB memory stick should be formatted in FAT32 format



Power on the SD One MF




Insert the USB memory stick, with the unzipped file, in the USB connection next to the touchscreen




Check that the USB memory is recognized by the system



Swipe and select settings




Select 'System'



Select 'Update'



Select 'OK' to start the update process



System will now reboot and start up in update mode $% \left(1\right) =\left(1\right) \left(1\right) \left($

Select 'Install from USB stick'



Select to upgrade to the newer version



The upgrade process will now start



Select 'OK' when the upgrade is completed



Remove the memory stick and select 'Return to normal operation' $% \left(1\right) =\left(1\right) \left(1\right) \left($



System will now reboot....



System update completed!